


SHIMANO®

CALCUTTA ⚙️ A-RB

CT-400B



Part No.	Description	Part No.	Description	Part No.	Description
BNT0009	Cast Control Spacer	BNT1618	Key Washer	BNT1704	Click Plate
BNT0032	Bearing Retainer	BNT1620	Eared Washer	BNT1705	Click Spring
BNT0042	Line Guide Pawl	BNT1627	Yoke	BNT1706	Click Switch Spring
BNT0060	Spacer	BNT1628	Clutch Cam Retainer	BNT1838	Washer
BNT0133	E Lock	BNT1629	Clutch Cam	BNT1853	Key Washer
BNT0151	Pawl Cap	BNT1633	Level Wind Guard	BNT2061	Drag Washer
BNT0188	O Ring	BNT1634	Level Wind Guide	BNT2062	Drag Washer
BNT0425	E Lock	BNT1635	Worm Bushing A Retainer	BNT2063	Drag Washer
BNT0586	O Ring	BNT1636	Screw	BNT2098	Cast Control Cap
BNT0623	Screw	BNT1639	Idle Gear A / Click Gear	BNT2473	Star Drag Spacer
BNT0686	E Lock	BNT1641	Side Plate Bolt	BNT2926	Roller Clutch Inner Tube
BNT0770	Screw	BNT1643	Clutch Bar Support	BNT2927	Ball Bearing
BNT0799	Friction Washer	BNT1646	Screw	BNT3107	Line Guide
BNT0819	Drive Shaft Bushing	BNT1647	Washer	BNT3290	Washer
BNT1133	Yoke Spring	BNT1648	Idle Gear B	BNT3309	Brake Collar
BNT1201	Retractor Spring Collar	BNT1649	Idle Gear Shaft	BNT3356	Handle Assembly
BNT1215	Anti-Reverse Ratchet	BNT1650	Brake Ring	BNT3357	Star Drag
BNT1223	Retractor Spring	BNT1651	Click Shaft	BNT3358	Right Side Plate
BNT1227	Push Nut (SPN-2)	BNT1652	Screw	BNT3359	Drive Gear
BNT1237	Screw	BNT1654	Click Link	BNT3360	Pinion Gear
BNT1243	Worm Bushing B	BNT1656	Click Pawl	BNT3361	Anti-Reverse Pawl
BNT1245	Spacer	BNT1658	Click Switch	BNT3362	Set Plate
BNT1293	Retractor Spring Pin	BNT1659	Lock Washer	BNT3363	Spool Assembly
BNT1302	Screw	BNT1660	Spacer B	BNT3365	Clutch Bar Guide B
BNT1306	Clutch Pawl	BNT1663	Handle Nut Plate	BNT3367	One-Piece Frame
BNT1307	Clutch Pawl Spring	BNT1696	Cast Control Spacer B	BNT3368	Left Side Plate
BNT1337	Spacer	BNT1697	Spool Tension Spring	BNT3441	Handle Nut
BNT1455	Drag Spring Washer H	BNT1698	Side Plate Bolt	BNT3442	Drive Shaft
BNT1476	Spacer	BNT1699	Worm Bushing A	BNT3466	Clutch Plate
BNT1494	Washer	BNT1700	Worm Shaft	BNT3467	Clutch Bar Guide A
BNT1613	Drag Spring Washer L	BNT1702	Washer	BNT3468	Quick-Fire II Clutch Bar
BNT1616	Screw	BNT1703	Idle Gear C	BNT3469	Clutch Bar Set