


SHIMANO

CALCUTTA TE SA-RB

CTE-400LJV



Part No.	Description	Part No.	Description	Part No.	Description
BNT0006	Friction Washer	BNT2452	Clutch Bar Guide A	BNT2720	Click Link
BNT0011	Screw	BNT2457	Pawl Cap	BNT2721	Click Switch Cam
BNT0032	Bearing Retainer	BNT2462	Damper Guide	BNT2722	Click Link Pin
BNT0060	Spacer	BNT2680	Handle Nut	BNT2723	Click Switch Spring
BNT0586	Bolt Retainer	BNT2684	Screw	BNT2724	Click Spring Pin
BNT0686	E Lock	BNT2686	Screw	BNT2725	Line Guide
BNT0687	Spacer	BNT2687	Screw	BNT2726	Washer
BNT0770	Screw	BNT2688	Cam Backing Plate	BNT2727	Damper Bush
BNT1201	Retractor Spring Collar	BNT2689	Drag Washer	BNT2729	Idle Gear
BNT1223	Retractor Spring	BNT2690	Key Washer	BNT2730	Spacer B
BNT1243	Worm Bushing B	BNT2691	Base Drag Disc	BNT2731	Brake Case
BNT1419	Yoke Spring	BNT2692	Drag Washer	BNT2732	Washer
BNT1455	Drag Spring Washer H	BNT2693	Drive Gear	BNT2733	Idle Gear
BNT1613	Drag Spring Washer L	BNT2694	Drag Washer	BNT2734	Screw
BNT1636	Screw	BNT2695	Drag Click Plate	BNT2735	Idle Gear Shaft
BNT1672	E Lock	BNT2696	Anti-Reverse Ratchet	BNT2736	Side Plate Spring
BNT1696	Cast Control Spacer	BNT2697	Drag Click Pin Holder	BNT2950	Roller Clutch Inner Tube
BNT1713	Brake Collar (green)	BNT2698	Drive Shaft	BNT3621	Ball Bearing
BNT2122	Click Pin	BNT2699	Washer	BNT3633	Ball Bearing
BNT2123	Click Spring	BNT2700	Washer	BNT3812	Ball Bearing
BNT2125	Star Drag Spring	BNT2701	Click Gear	BNT3890	Handle Nut Plate
BNT2128	Bearing Washer	BNT2702	Washer	BNT3891	Handle Assembly
BNT2150	Line Guide Pawl	BNT2703	Worm Bushing Retainer	BNT3892	Star Drag
BNT2165	Clutch Cam Retainer	BNT2704	Washer	BNT3893	Click Switch
BNT2224	Spool Tension Spacer	BNT2705	Worm Bushing A	BNT3894	Right Side Plate
BNT2228	Screw	BNT2707	Level Wind Guard	BNT3895	Worm Shaft
BNT2404	Anti-Reverse Pawl	BNT2708	Level Wind Guide	BNT3896	One-Piece Frame
BNT2425	Side Plate Open Nut	BNT2709	Pinion Gear	BNT3897	Clutch Bar Guide B
BNT2426	Washer	BNT2710	Clutch Cam	BNT3898	Quick-Fire II Clutch Bar
BNT2427	O Ring	BNT2711	Clutch Pawl Spring	BNT3899	Idle Gear
BNT2428	Cast Control Cap	BNT2712	Clutch Plate	BNT3900	Spool Assembly
BNT2429	O Ring	BNT2713	Retractor Spring Pin	BNT3901	Left Side Plate
BNT2430	Key Washer	BNT2715	Clutch Bar Support		
BNT2437	Drive Shaft Retainer	BNT2717	E Lock		
BNT2446	Yoke	BNT2718	Click Spring	BNT1715	Brake Collar (red) (accessory)
BNT2449	Clutch Pawl	BNT2719	Click Pawl	BNT2738	Wrench (accessory)