


TEAM DAIWA-Z105HL



Key No.	Parts No.	Parts Name
1	F83-7901	R/S PLT
2	F63-1301	SET PLT SCREW
3	E16-7101	SET PLT SPRING
4	F61-3302	BRAKE ADJ KNOB
5	B33-9801	BRAKE DIAL RET A
6	F63-7701	BRAKE DIAL WASHER
7	F05-1701	BRAKE CLICK SPRING
8	F61-3401	BRAKE DIAL RET B
9	F83-8001	RIGHT SET PLT
10	F93-9701	RIGHT SET PLT SCREW
11	F71-7702	MAGNET HOLDER
12	B54-3201	MAGNET HOLDER RET RING
13	375-7404	SPACER A
14	375-7411	SPACER B
15	F57-4303	SPACER C
16	F57-7702	BALL BEARING A
17	E21-9701	BEARING RET A
18-26	Z01-1452	SPOOL
27	F83-4001	FRAME
28	F83-7501	REAR COVER
29	351-1006	REAR COVER SCREW A
30	351-1107	REAR COVER SCREW B
31	320-5901	WORM SHAFT RET
32	F65-5501	WORM SHAFT WASHER
33	B71-5601	WORM SHAFT HOLDER
34	F83-6501	LEVEL WIND GUARD
35	F83-6201	LINE GUIDE PAWL HOLDER
36	121-4212	LINE GUIDE PAWL
37	F95-0200	LINE GUIDE WASHER
38	342-4801	PAWL CAP
39	F05-5601	BALL BEARING B
40	F83-6601	WORM SHAFT
41	F95-8401	DRIVE GEAR A
42	F28-3101	BALL BEARING C
43	F50-5701	DRIVE GEAR SCREW
44	F83-6001	DRIVE GEAR B
45	F83-6401	STABILIZER BAR
46	F83-7601	FRONT PLT
47	F83-4701	BALL BEARING COLLAR
48	B86-1701	BALL BEARING D
49	F83-5001	CLUTCH CAM
50	F83-5801	YOKE
51	F58-8001	YOKE SPRING
52	F83-4901	CLUTCH TRIP PLT HOLDER
53	F83-4801	CLUTCH TRIP PLT
54	F77-4603	CLUTCH TRIP PLT WASHER

Key No.	Parts No.	Parts Name
55	320-5901	CLUTCH TRIP PLT RET
56	F86-5301	CLUTCH LEVER
57	F94-5001	CLUTCH LEVER SPRING
58	F83-5401	CLUTCH LEVER WASHER
59	F83-5301	CLUTCH LEVER SCREW
60	F84-5401	PINION GEAR
61	E21-9701	BEARING RET B
62	F05-5601	BALL BEARING E
63	F83-3401	L/S PLT
64	351-1107	L/S PLT SCREW A
65	F80-0501	PINION SHAFT
66	B17-5401	SPOOL ADJ CAP METAL
67	B17-5503	SPACER D
68	F83-3901	CAST CONTROL CAP
69	F64-7201	DRIVE SHAFT WASHER A
70	F05-5601	BALL BEARING F
71	F83-5701	DRIVE SHAFT RET
72	F68-9501	CLUTCH TRIP PLT SPRING
73	F21-1101	DRIVE SHAFT RET SCREW
74	F83-5601	DRIVE SHAFT
75	F83-6901	A/R RATCHET
76	E42-5301	DRIVE SHAFT WASHER B
77	F83-7001	DRIVE GEAR
78	F79-6102	EARED WASHER
79	F79-6201	DRAG WASHER A
80	F79-6303	KEY WASHER A
81	F79-6401	KEY WASHER B
82	E42-5401	SPACING SLEEVE
83	F60-2901	GEAR SHAFT COLLAR
84	B55-3802	SPACING SLEEVE B
85	F57-3901	ROLLER CLUTCH
86	F58-2501	BALL BEARING G
87	B55-3801	DRIVE SHAFT WASHER C
88	F02-8201	CLICK LEAF SPRING HOLDER
89	F03-2401	CLICK LEAF SPRING
90	150-8901	DRAG SPRING WASHER
91	373-7810	SPACING SLEEVE C
92	F57-6503	STAR DRAG
93	F57-6601	FRICTION WASHER
94	F83-7201	HANDLE
95	F83-7401	HANDLE NUT
96	F57-7202	HANDLE NUT RET
98	351-1006	L/S PLT SCREW B
99	F96-7801	DRAG WASHER B
100	F26-2701	CAST CONTROL CLICK SPRING