



KEY NO.	DESCRIPTION	PART NO.	KEY NO.	DESCRIPTION	PART NO.
		SX 10			SX 10
1	SPACE WASHER	1195751	41	HANDLE SCREW COVER	1279189
2	O-RING	1195755	42	SCREW (6 REQ)	1279194
3	BEARING SLEEVE	1195758	43	BEARING RETAINER (2 REQ)	1279200
4	BALL BEARING	1195757	44	OSCILLATION MOUNT	1279207
5	SEAL	1195761	45	IDLER GEAR	1195767
6	SPOOL SHAFT WASHER	1195763	46	SCREW	1221496
7	SPOOL SHAFT	1252579	47	GEAR BOX	1279209
8	SCREW	1195642	48	SCREW (2 REQ)	1279218
9	SCREW (2 REQ)	1252582	49	SWITCH SPRING	1221500
10	WASHER(2 REQ)	1252583	50	SWITCH LEVER	1221501
11	BAIL ARM	1279160	51	IAR SWITCH	1279221
12	BALL BEARING	1252587	52	CLIP	1221504
13	LINE ROLLER	1279162	53	STEM	1279225
14	POM BUSHING	1279163	54	GUIDE BAR	1221428
15	BRASS BUSHING	1279165	55	MAIN GEAR	1252627
16	O-RING	1195591	56	SHIM	1195560
17	CLIP	1195592	57	HANDLE ASSEMBLY	1279230
18	BAIL HOLDER	1279167	58	BALL BEARING	1195641
19	BAIL WIRE	1252593	59	POM BUSHING	1279234
20	SCREW	1252594	60	BRASS BUSHING	1279238
21	ROTOR LOCKING PLATE	1195770	61	OSCILLATION GEAR	1252634
22	ROTOR NUT	1195643	62	SCREW	1195812
23	SCREW (2 REQ)	1221462	64	OSCILLATION SLIDER	1252636
24	BAIL ARM COVER	1279178	65	DRAG KNOB	1279244
25	PIVOT LEVER	1195617	66	SPOOL	1279246
26	BAIL SPRING BUSHING	1195619	67	LINE CLIP SPRING	1252661
27	BAIL SPRING	1252598	68	LINE CLIP	1279254
28	BAIL TRIP BAR	1252599	69	KEY WASHER (2 REQ)	1221544
29	BUSHING (2 REQ)	1221467	70	SPOOL WASHER	1221549
30	ROTOR	1279181	71	DRAG WASHER 1	1279258
31	BAIL HOLDER COVER	1279184	72	DRAG WASHER 2	1195729
32	SCREW (3 REQ)	1195572	73	O-RING	1195726
33	BEARING HOLDER COVER	1252604	74	SPOOL CLICK RETAINER	1221554
34	BALL BEARING (4REQ)	1181780	75	SPOOL CLICK	1221555
35	BEARING HOLDER	1252605	76	SPOOL BOTTOM	1221556
36	CLUTCH ASSEMBLY	1195773	78	SPOOL ASSEMBLY	1279266
37	CLUTCH SPRING	1252606	79	SPARE SPOOL ASSEMBLY (Not Shown)	1279270
38	PINION	1252607			
39	SCREW (5REQ)	1195720			
40	ROTOR BRAKE	1252610			